400.00 mm

80.00 mm

95.00 mm

2D Barcode Scanner User's Manual

V4.0.4

Introduction

In order to facilitate users to use the product quickly, the functions set in this manual are simple version, and the setting codes of all functions are not listed. For more setting functions, please ask the supplier for the electronic version of the complete manual, and the setting code marked with * is the default setting.

System settings

Restore factory settings

Restore factory settings

The scanner cannot be used normally due to error in setting or forgetting the previous setting. The factory setting can be restored and the normal use function can be restored.

Interface settings

USB*

Input barcode information by USB-HID keyboard. No driver software is required. (Default with driver).

USB virtual serial port

The virtual serial port mode can be used only after the driver is installed, otherwise the host will not recognize the scanner.

RS232

Serial cable is required, otherwise the data can't be transmitted.

Terminator settings

None

CR*

LF

CR/LF*

TAB

QR Code URL Link

Disable

Enable*

Inverse barcode settings

Normal barcode*

Both Normal and Inverse barcode

Normal barcode is black barcode with a white background.
Inverse barocde is white barcode with a black background.

95.00 mm

Successful decoding beeper settings (tone)

Low volume

High volume*

Successful decoding beeper 1*

Successful decoding beeper 2

Successful decoding beeper 3

Language settings

English

French

Italian

German

Spanish

Finnish

Japanese

Language settings

Russian

Arabic

Irish

Polish

Dutch

Czech

Language settings

Portuguese

Swedish

Turkish Q

Greek

Hungarian

Universal

Other settings

Enable all codes

Only the common codes are enabled with default, after scan "Enable all codes" support all codes decoding.

Version information