Enable/Disable Configuration

Scanner only can be set when configuration function is enabled.



Enable Configuration Function (Default)



Disable Configuration Function

Version No.



Version Number

Factory Default Setting



Reset Factory Default Configuration

User Configuration

Save current parameters as user’s configuration.



Save

Reset scanner to user’s configuration.



Reset User Configuration

Data Interface



USB-KBW (Default)



RS232



USB Virtual Com(*driver is needed)

USB Keyboard Layout

Control Character Escaping



Enable Escaping Mode 1



Enable Escaping Mode 2



Disable (Default)

Other Character Escaping



Enable



Disable*

CR/LF Setting(USB-KBW)



Only 0A(LF) line feed



Only 0D(CR) line feed (Default)



0A(LF) and 0D(CR) both line feed

USB-KBW Transfer Speed

Set the data transfer speed under USB-KBW interface. If the PC is an old version with lower performance, please choose low transfer speed to ensure the accuracy of data transfer.



Low (Default)



Middle



High



Custom Transfer Speed (2ms~50ms)

Convert Case



Original data (Default)



Case Inversion



All Convert to Upper Case



All Convert to Lower case

Keyboard Layouts



English (United States) (Default)



French (France)



Italian (Italy)



Italian 142 (Italy)



German (Germany)



Spanish (Spain)



Spanish (Latin America)



Finnish



Japanese



Russian (MS)



Russian (typewriter)



Arabic (101)



Irish



Polish (214)



Polish (Programmers)



Dutch (Netherlands)



Czech (QWERTZ)



Portuguese (Portugal)



Portuguese (Brazil)



Swedish (Sweden)



Turkish Q



Turkish F



Greek (MS)



French (Belgium)



English (UK)



Hungarian



Hungarian 101-KEY



Vietnamese



Slovak

Virtual Keyboard

Mode 1: Disable output characters between 0x20 to 0xFF by virtual keyboard.
Enable output characters between 0x00~0x1F by control characters definition(refer to Appendix).